




Bluetooth standard	Bluetooth 5.0ble			
Network connection	2.4G WiFi 802.11b/g/n			
Support for mobile phone systems	Android 4.3/IOS7.0以上			
Power supply mode	For 7.4 V lithium battery 5000	mah		
Low alarm voltage	7.2V			
Voltage Range	5^{9V}			
Standby current	550 microamps (Cat's eye face)	e, radar,		
Working Current	<3A (mean)			
Operating temperature range	-20 to 70 degrees Celsius			
Number of passwords	Custom and permanent passwords	250		
	Other dynamic passwords	No restric tions		
The card types supported	Mifare M 1 card			
Number of IC cards	1,000			
Remote control	A lock can be added to 15 remote a remote control can only be a lock.			
Unlock mode	App, face, password, fingerprint mechanical key, remote control	, IC card,		
Type of fingerprint head	Semiconductor fingerprint head			
Fingerprint capacity	100 fingerprints			
False recognition rate (FAR)	<0.001%			
Face recognition				
Recognition speed	0.5 S (hot start) , 1.4 s (cold	start)		
Identify the distance	0.4 m ~ 1 m, 0.6 m is the best			
Biopsy	TAR: 98% FAR: 1 in 100,000			
Biopsy Face comparison Maximum number of face support users	TAR: 98% FAR: 1 in 100,000 TAR: 98% FAR: one in a million 50			
Biopsy Face comparison Maximum number of face support users Cat's eye	TAR: 98% FAR: one in a million 50			
Biopsy Face comparison Maximum number of face support users	TAR: 98% FAR: one in a million			
Biopsy Face comparison Maximum number of face support users Cat's eye	TAR: 98% FAR: one in a million 50 2 million HD CMOS sensors; 0.1 lu in color, 0.01 lux@F1.2 in bla	ck and		
Biopsy Face comparison Maximum number of face support users cat's eye Sensors	TAR: 98% FAR: one in a million 50 2 million HD CMOS sensors; 0.1 lu in color, 0.01 lux@F1.2 in bla white HD: 1960 * 1080@12fps smooth	ck and h: 640 *		
Biopsy Face comparison Maximum number of face support users cat's eye Sensors Image output	TAR: 98% FAR: one in a million 50 2 million HD CMOS sensors; 0.1 lu in color, 0.01 lux@F1.2 in bla white HD: 1960 * 1080@12fps smooth 360@25fps High Definition security mirror, 5	ck and h: 640 *		
Biopsy Face comparison Maximum number of face support users cat's eye Sensors Image output Camera	<pre>TAR: 98% FAR: one in a million 50 2 million HD CMOS sensors; 0.1 lu in color, 0.01 lux@Fl.2 in bla white HD: 1960 * 1080@12fps smooth 360@25fps High Definition security mirror, 2 angle, height 13 ± 0.2 mm</pre>	ck and h: 640 *		
Biopsy Face comparison Maximum number of face support users cat's eye Sensors Image output Camera The nearest object distance Switch between day and night	<pre>TAR: 98% FAR: one in a million 50 2 million HD CMOS sensors; 0.1 lu in color, 0.01 lux@Fl.2 in bla white HD: 1960 * 1080@12fps smooth 360@25fps High Definition security mirror, 1 angle, height 13 ± 0.2 mm 0.3m</pre>	ck and h: 640 *		
Biopsy Face comparison Maximum number of face support users cat's eye Sensors Image output Camera The nearest object distance Switch between day and night mode	<pre>TAR: 98% FAR: one in a million 50 2 million HD CMOS sensors; 0.1 lu in color, 0.01 lux@F1.2 in bla white HD: 1960 * 1080@12fps smootl 360@25fps High Definition security mirror, 1 angle, height 13 ± 0.2 mm 0.3m Support for IR-CUT</pre>	ck and h: 640 * 138° wide		

Once the door lock is installed, if there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock, it will unlock the door. If there is a lock button for the door lock button for the door

1

Inclusion is the clock of the calibration flow first is a grateway, it will be calibrated through ends to be calibrated by the Bluecoto of the mobile phose is to the lock.Image: Calibration flow flow flow flow flow flow flow flow	Lock Clock		
Diagnostics will Upload the Config Data to our Server for Root Cause Analysis of the problem. Please execute within 2 meters of the Lock. Upload Data This Operation will Read all records stored in the Lock. It may take some time, please be patient. Upload Data Inport From Another Lock. Import From Another Lock. It is one via bluetooth, so make sure you are near to the new lock. It is one via bluetooth, so make sure you are near to the new lock. Import From Another Lock It is one via bluetooth, so make sure you are near to the new lock. It is one via bluetooth, so make sure you are near to the new lock. It is one via bluetooth next to the to key, "Settings" menu, select the old lock and start to import. It is one via bluetooth so make sure you are near to the new lock. Import From Another Lock Import From Another Lock It is one via bluetooth next to the permission on the old lock and start to import. It is one via bluetooth next to the permission on the lock in the app. Firmware upgrade is succ	there is a gateway, it will be calibrated through the gateway first, and when there is no gateway, it needs to be calibrated by the Bluetooth of the mobile phone	Calibrate Time	
Updated bate This Operation will Read all records stored in the Lock. It may take some time, please be patient. Updated data from inckt to server. It may take Import From Another Lock Replace old lock with a new one, and want the permissions on the old lock work on new lock. Click "Import from another lock" in the lock's "Settings" menu, select the old lock and start to import. It is done via bluetooth, so make sure you are near to the new lock. Firmware Update The lock can be upgraded via the app. Firmware upgrades need to be made via Bluetooth next to the lock, after the upgrade is successful, the original key, password, IC card, fingerprint and other	Diagnostics will Upload the Config Data to our Servers for Root Cause Analysis of the problem. Please execute	Diagonatics will lubicat the Config Data to our Servers for Root Cause Analysis of the problem: Please execute within 2 meters of the Lock.	
Replace old lock with a new one, and want the permissions on the old lock work on new lock. Import from another lock "in the lock's "Settings" menu, select the old lock and start to import. Import from another lock "in the lock's "Settings" we was allowed by the new lock. It is done via bluetooth, so make sure you are near to the new lock. Import from another lock "in the lock's "Settings" we was allowed by the new lock. Import from another lock "in the lock's "Settings" we was allowed by the new lock. Firmware Update Import from another lock and by the app. Firmware upgrades need to be made via Bluetooth next to the lock. After the upgrade is successful, the original key, password, IC card, fingerprint and other Import from another lock and the lock and	• This Operation will Read all records stored in the Lock.	Upload data from lock to server. It may take several minutes	
Firmware Update Image: State of the sta	Replace old lock with a new one, and want the permissions on the old lock work on new lock. Click "Import from another lock" in the lock's "Settings" menu, select the old lock and start to import.	No buts	(
The lock can be upgraded via the app. Firmware upgrades need to be made via Bluetooth next to the lock. After the upgrade is successful, the original key, password, IC card, fingerprint and other	the new lock.	from another face. (no frequencies)	
	upgrades need to be made via Bluetooth next to the ock. After the upgrade is successful, the original key, password, IC card, fingerprint and other	Current Version: 6.5.01.231904	










Knob tail saw off the mark Spring Tail can be cutted short if long

8 CONNECT CABLES













,	No Data Add door sensor				
			Click nex	t when the light flashes q	uickly
Remote Unlock This Feature allows you to Unlock the Smart Lock Re- motely via a Gateway. This Feature can ONLY be furned ON or OFF via Bluetooth.	the State T to State	₹3∎D Lack LY be			
Auto Unlock	⊷⊷e3gege ₹ 1639 ✓ Auto Unlock Auto Lock Delay time	** 🕶	•••••• 	1659 Auto Unlock	≠ \$ ==0
utomatically after the set time.Find "Auto Lock" in the ock's setting menu. Enable this feature by setting a ime. Please unlock it for one time first to make the setting available.	The lock will lock automatically after the t Please unlock in for one time first to make setting available.		Cancel	Time 10s	ок
				15s 30s 60s Custom	



QR Code Lock Unlocking	·····•+===== *		78
	Permanent	Timed	Recurring
All the generated QR codes will be listed here.	Name		Please enter her
n the QR code's detail page, you can view, change,	Start Time		2022.12.16 15:3
hare, and delete it.	End Time		2022.12.16 15:3
elete validity period type and enter the name to			
reate a OR code. The OR code link can be send to			

















mode and add it with app.

There are three user levels: administrator, authorized administrator,	Loss Loss Loss Loss Loss	******	eete > 1639 Admin ek	* * -
and user. When you add a lock with App, you will be the administrator		Timed		\$15
of this lock. The administrator can add others as the authorized		Recip	ant Enter Br	ecipient's Account 🕥
administrators. Both the administrator and authorized administrator		Name		Please enter here
can grant access permission to others. Users have the permission to	<u>ت</u>	Natio		
unlock with App.	No Data		Send	
First, select a lock and run into the console page.				
Click "Authorized admin", you can see all current authorized				
administrators of this lock.				
Click "Create admin", enter the account and validity period, then				
lick "Send".	Create Admin			
The authorized administrator has almost the same permission as the				
administrator, except for some special functions.				

10 Records	~ ·····
	Q Sea
Look up all operations in the "Records" page. You car	2022.12
delete or export the records.	185 14:
The administrator can clear all the records.	2022.12
Click "Export records" at the top right menu. You car	
export the records of last half year.	2 15: 15:
The administrator can query the unlock record of each	ו 🌀 דד 🌕 ו
key.	

 arch

 2.12.16

 1655
 961

 147:22.24 Milds
 MAP

 022.12.15
 10

 150:07.07 Milds with APP
 1150:730 Milds with APP

 150:07.09 Milds with IC card
 150:730 Milds with IC card

 150:07.05 Milds with IC card
 150:730 Milds with IC card

 150:07.05 Milds with IC card
 150:64.41 Milds with IC card







Note:1.Install battery first and then screen.2 Tight the screen to lock panel without chink




screws







3



There are two ways to add a face. • Select the type, enter the name, and select "From lock" as the add method. Follow the prompts to align the face with the lock's camera.



 \circ Select "From photo" as the add method. Select a photo that meets the requirements and preview the effect. If you are not satisfied, you can "Replace". Click "OK" to complete the addition.




6 Palm Vein

• You can see the palm vein that has been added here. There are "Reset" and "Sensitivity" in the menu. Click "Reset" to delete all palm vein data; click "Sensitivity" to adjust the camera's recognition sensitivity.

• You can enter the palm vein details page from the list to view, modify, and delete.

• Select the type, enter the name, follow the prompts to align your palm with the lock's camera, and record the palm vein.



5

Deadline Warning

System will show two colors for deadline warning. The

18

3 Cards

Add Card You need to add the IC card first. The whole process CO22.12.15 15:05 Permane needs to be done via the app beside the lock. The validity CO22.12.15 15:05 Permanent period of the IC card can be set, either permanent or STIlock3 2022.12.15 15:05 Permar time-limited. Card list: All cards of this lock will be listed here. Click "Reset" at the top right to delete all of them. Selete validity period type and enter the name, then place the card on the lock to be added. CAdd Card

IC Card Management

In the card's detail page, you can view, change, or delete it. Android NFC Card Issuance Android phones can issue cards NFC (gateway required).

④ Fingerprint


Fingerprint management is similar to IC card management. After adding a fingerprint, you can use the fingerprint to unlock the door.


5 Face

• All faces of this lock will be listed here. Click "Reset" at the top right delete all of them. Click "Sensitivity" to set the sensitivity of the camera on the lock.


17

• In the face's detail page, you can view, change, and delete it.





4







6

Scan to download The App

Computer

APP

Web

Download :http://download.ttlock.com/appDownload/ttlock/TTLock_Card_Encoder_setup_1.2.0.exe


Contents	A	PP 🗸
1.Registration And Login—	—03~04	Overview Of Key Features-
1.1 Register	03	
1.2 Security Question Settings	03	1 Key Management ——
1.3 Login Authentication	03	Send Ekey
1.4 Ways Of Identifying	04	Kau Managaran
2.Lock Management ——	04	Deadline Warning
2.1 Lock Adding	04	② Passcodes ———
2.2 Add Wifi Smart Lock ————	04	
		Generate Passcode
3. Gateway	05	Password Management
3.1 Gateway Type	05	③ Cards
3.2 Add Gateway	05	Add Card
3.3 Gateway Functionality	05	IC Card Management
	05	Android Nfc Card Issuance
5.Customer Service ——	06	Fingerprint
		⑤ Face ————
6. Settings	— 06~09	6 Palm Vein —
6.1 Sound	06	
6.2 Touch To Unlock ————	06	⑦ QR Code
6.3 Notification Push	06	
6.4 Lock Users —	07	QR Code Lock Unlocking
6.5 Authorized Admin ————	07	8 Remote
6.6 Lock Group	07	
6.7 Transfer Lock —	07	9 Authorized Admin ——
6.8 Transfer Gateway	07	
6.9 Languages ————————————————————————————————————	08	10 Records ———
6.11 Hide Invalid Access ————	08	1 Lock Settings ———
6.12 Locks Requiring phone Online ——	08	
6.13 Services	08	Basics
5.14 About	09	Wireless Keypad
6.15 Logout		Door Sensor
6.16 Delete Account	09	Auto Unlock —
		Passage Mode
7. Work with	—— 09	Lock Sound
		Tamper Alert
		Privacy Lock
		Lock Clock
		Diagnosis Upload Data
		Import From Another Lock — Firmware Update —
		Firmware Undate

yellow means close to expiring and the red means it has expired.	Q. Search	1.10 14:11		
2 Passcodes	••••••中国电信令 16: (Generate	99 • * = D Dasscode	••••••انتقادی کې ادغا ح Generate passcoo	≁∦ ≡0
Generate Passcode		-time Custom Recurring	Permanent Timed One-time	
You can see all passcodes here. Press "Reset" at the	This Descords MUST BE used at less	a name for this Passcode		
op right to delete all of them.	Current Time, or it will be SUSPENE	DED for Security Reasons.	Succeeded. The Passor	ide is
'ou can also create an "Erase" passcode to delete all other passcodes. Or create a custom passcode.	Generate	Passcode	02025439	
Erase: When you input "Erase" passcode on lock, all				
other passcodes will be disabled.				
Dne-time passcode only works within 6 hours.			Complete	
he passcodes with type permanent, timed, and recurring should be sed at least once after their "start time". Or they will be invalidated.			Share	
	·····⊙+@8##⇒ 16: ← Generate	99 🔹 🕫 🕫 🕫		
	Comp	olete		
	Sha	ire		
	Send Pass	icode via		
	0 0			
	SMS Em			
	Car	cet		
Decement Management	•••••0年回老信 专 16	59 * 8 🗖		
Password Management	e passco Passcode	de info 🗾 02025439 >		
a the managed data it many user and view.	Name	T T lock >		
n the passcode's detail page, you can view, hange, share, and delete it.	Validity Period	Permanent >		
nange, snare, and delete it. Inly passcodes have been used on lock can be	Issued by	185 961		
hanged.	Time Issued	2022.12.15 14:16		
-	Records	>		
	Del	ata		
	Deb	210		

16

Overview Of Key Features

After adding lock, you can grant access permissions to others, including ekey, passcode, card, fingerprint, face, and etc.



Send Ekey

You can see all ekeys here. Press "Reset" at the top right to delete all of them. In the ekey's detail page, you can view, change, freeze, and delete it. Click "Send eKey" to send ekey to someone else. If the recipient account hasn't been registered yet, it will be registered automatically. A SMS message or email with password will be sent. Remote unlock: Gateway is needed to do remote unlock.Identity verification: (It only works in China).

****0 中国电信 学	16.59	**	****0中国电话	1 🗢 1639	1800	****0中国电	iii ⊘	16:59	* 8 🗖	****0 403	(8.C ♥	16:59	**
\leftarrow		Reset	÷			\leftarrow				\leftarrow			
Q. Search			Timed Pi	ermanent One-time	Recurring	Timed	Permanent	One-time	Recurring	Timed	Permanent	One-time	Recurring
Permanent		Pending	Recipient	Enter Recipier	nt's Account 🚺	Recipient	:	Enter Recipi	ent's Account 🚺				

1.Registration And Login 1.1 Register

Users can register the account by mobile phone and Email which currently support 200 countries and regions on the world. The verification code will be sent to user's mobile phone or email, and the registration will be successful after the verification. When you send an ekey to a phone number or email, and this phone number or email hasn't been registered yet, they will be registered automatically.

Phone 🔫						Email	•	
•••中国电池 *	28:59 Register	**=0	●中国电信令 20:39 - Choose your Counti	+ * = 0 y or Region	D	·····•	ार १८२० Register	41
Pho	ne Email		Search				Phone Email	
Country/I	Region China+	86	Afghanistan	+93 C	3	1	Enter your Email	
👤 Ent	er your Phone number		Azerbaijan	+994 E	5	Å	Password between 6-20	chars
Pas:	sword between 6-20 ch	ars	Oman	+968 G H	5	3	Confirm Password	
			United Arab Emirates	+971 J	1	-		
Verification	Code Get Cor	le	Albania	+355 L		Verifi	cation Code Get	Code

1.2 Security Question Settings

3. Gateway

You will be taken to the security question settings page when registration is successful. When log in on a new device, the user can authenticate himself by answering the above questions.

Security Questions Setting Security Questions Setting Security Questions Setting Sett	Scorify Questions Setting bocartly Questions Setting bocartly Questions Setting bocartly Questions when using a New Dovice Where ddyou goth instreme you flevon a plane? Please type in your Answer What is your QQ number? Please type in your Answer
Associate Verder Sport Annuel Annuel Sport Annuel Annuel Sport Annuel Annuel Sport Annuel A	Security Questions when using a New Dévice Where did you go the first time you flew on a plane? Please type in your Answer What is your QQ number?
security Questions when using a trea Bevice Security Question 1 Security Question 1 Please type in your Answer Please Select a Question Question 2 Where did you go the first time you flew on a plane?	Please type in your Answer What is your QQ number?
Please type in your Answer Please Select a Question Question 2 Where did you go the first time you flew on a plane? Please type in your Answer	What is your QQ number?
Verse stype in your Answer Verse did you go the first time you flew on a plane? Devant time in your Answer	
Please time in your Answer	Please type in your Answer
Please type in your Answer What is your QQ number?	
	What was the Name of your First Pet?
uestion 3 > What was the Name of your First Pet?	Please type in your Answer
Please type in your Answer	ОК
OK Cancel	

1.4 Ways Of Identifying

2.2 Add Wifi Smart Lock

according to the prompt;

cate that it can be added;

connected to and enter the password.

the interface;

(2) Select Add Lock;

(1) Call out menu interface in the upper left corner of

(4) The door lock name has a "+" sign in black to indi

(5) After the addition is successful, select the WIFI to be

(3) Select the corresponding type of door lock to add it 🛛 🕒 M501_890821

There are two ways of security verification. One is the way to get the verification code via the account number, and the other is the way to answer the question. If the current account is set the "answer the question" verification, then when the new device is logged in, there will be an "answer question verification" option.


7



The App supports multiple types of lock, including door locks, padlocks, safe locks, smart lock cylinders, parking locks, and bicycle locks. When adding a device, you must firstly select the lock type. The lock needs to be added to the app after entering the setting mode. A lock that has not been added will enter the setting mode as long as the lock keyboard is touched. The lock that has been added needs to be deleted on the App first. The added lock will be shown in the lock list, together with lock name and battery level. To add a lock, please wake it up first by touching the keypad, or swiping card. If the lock has been woken up but still not in setting mode, it may has been added by others yet. Please reset it first then try again.

2.1 Lock Adding	← Choose Lock Type	■ •••••●Ⅲ年数 辛 16.59 ← Nearby Lock:
(1) Call out menu interface in the upper left corner of the interface:	All Locks Scan all types of locks	MG01_42ae85
(2) Select Add Lock;	- Door Lock > 💍 Padlock	> K101C_5262a0
(3) Select the corresponding type of door lock to add it	☐ Safe Lock → ∞ Lock Cylinder	M501_a90a21
according to the prompt;	Safe Lock Stinder	M101T_093a07
(4) The door lock name has a "+" sign in black to indi	Parking Lock > Bicycle Lock	> B S202C_f65fc9
cate that it can be added.	Remote >	G01_b0097e
	- 001000	M101T_0de1f9
		MG01_c442a9

6.14 About	····o中面电信 ◆ 16 59 ← About	★ 1659 ★ 1659 ★ 0ur Story	* D
Call out the menu interface in the upper left corner of the interface, click Settings, select About, you can view	1	🖐 TTLOCK	
the version number and introduction of the TTlock APP,	TTLock 6.3.7	TTLock is a Global Leader in Design and Development of products based on Bluetooth a	and
the privacy policy and user agreement, as well as the	Our Story	> NB-IOT technology. Our focus and emphasis is	
list of personal information collection, application		Smart Locking Solutions using Cutting Edge, Reliable and Scalable Dual Homed Cloud base	d
permission description and third-party sharing information		Architecture.	
list.		Our wide range of Security Products and Solutions are designed to meet the stringent requirements of specific market segments like	
6.15 Logout	•••••●潮報☆今 1659 ← Settings	* \$ ■0) ••••••• #@#4@.\$ ♦ 1659 • •	\$ 0
	Languages En	glish > Authorized Admin	>
Call out the menu interface in the upper left corner of	Screen Lock	Off > Lock Group	>
the interface, click Settings, select Exit Account, and	Hide invalid access	Off > Transfer Lock	>
log out of the current account.	Locks requiring phone online	> Transfe Exit?	>
	Services	Cancel Logout glis	h >
	About		f>
	Logout		f>
	Colete A	Locks requiring phone online Ccount Services	>
			_
6.16 Delete Account	·····●中国电信 + 16.59 ← Settings	★ \$ ■0 ••••••••••••••••••••••••••••••••••	\$
All your Account Information will be Removed from the	Languages En	glish > Authorized Admin	>
Platform PERMANENTLY and cannot be Recovered. Do	Screen Lock	Off > Lock Group	>
you want to Delete?	Hide invalid access	Off > Transfe All your Account Information will	>
you want to belete:	Locks requiring phone online	> Transfe be Removed from the Platform	>
	Services	> PERMANENTLY and cannot be	









Key Management

	\leftarrow		÷	er Freez					
page, you can view,	Q. Search		Name	Authorize	т	ime Issued		2022.1	
change, freeze, and	TTlock	Pending	Validity Period	Perm	anent > R	ecords			
delete it.You can see	Permanent		Receiving account	17*	08	The Auth	norized User	has almost	Т
all ekeys here. Press			Issued by	18'	61			s as the Lock to Send eKeys	
"Reset" at the top			Time Issued	2022.12.1	5 13:42	and Pass		to send exeys	I
right to delete all of			Records		>	Can	ncel	Authorize	I
them.									
				Delete					
					_				





8



6.1 提



J301_6c90c8

K101C_5262a0

M101T_093a07

B \$202C_f65fc9

G01_b0097e

H101T_0de1f9

G01_c442a9

跳过

取消 选择网络 头

sciener RINERIN

Touch to Unlos

Notification push Lock Users

Authorized Admin

Lock Group

Transfer Lock


Off Screen Lock

Off >

Transfer Gateway

7. Work With	
Call out the menu interface in the upper left corner of the interface, select value-added services, you can purchase SMS and email; You can also activate the premium version of the function, including SMS template, email template, batch authorization administrator, group key, and batch group function.	Note Note Note Card Encoder Base card with out and encoder, without

14




6.11 Hide Invalid Access This Feature allows you to hide passcodes, ekeys,

Current status :Off cards, and fingerprints which are invalid for a period of time.



6.13 Services

Call out the menu interface in the upper left corner of the interface, click Settings, select value-added services, you can purchase SMS, email and real-name authentication; You can also activate the premium version of the function, including SMS template, email template, batch authorization administrator, group key, and batch group function.




13

0			H H
G1(Wi-Fi) Network: 2.4GWiFi	G2(Wi-Fi) Network: 2.4GWiFi	G3/G3P(PoE) Network: RJ45	G4(4G) Network: TLE (4G)
3.2 Add Gateway		ംംംം⇔≣ക്ലത് ഭരാ ⊀ുലാം ← Choose Gateway Type	
3.2 Add Gateway Gateways are added via an app	before they can be used. Here		
Gateways are added via an app are the steps: (1) open the APP; (2) Touch the" Ξ "icon on the		← Choose Gateway Type	← Add Gateway
Gateways are added via an app are the steps: (1) open the APP;	top left of the screen; ver it on;	Choose Gateway Type	← Add Gateway

3.3 Gateway Functionality





he user can consult and give feedback through the AI	**************************************	1659 **
ustomer service .	Cu:	service@ttlock.com
	Business	sales@ttlock.com
	Official Website	www.ttlock.com 💫
	Web System	lock.ttlock.com
	Hotel System	hotel.ttlock.com

6. Settings

6.1 Sound When using the TTLock APP to unlock, the phone will Touch to Unloc emit an alert tone, tap to set to turn on or off. Notification push Lock Users Authorized Admin Lock Group Transfer Lock Transfer Gateway

6.2 Touch To Unlock	← Settings		
	Sound		Sound
	Touch to Unlock		Touch to Unlock
There are lots of locks in your account, and you don't	Notification push		Notification push
want to search for a lock to open everytime.	Lock Users	>	Lock Users
Turn on the "Touch to Unlock" in the App "Settings"	Authorized Admin	>	Authorized Admin
menu. With this option on, you can open door by just	Lock Group	>	Lock Group
touching the lock to wake up it.	Transfer Lock	>	Transfer Lock
	Transfer Gateway	>	Transfer Gateway
	Languages	English >	Languages

6.3 Notification Push

Receive the notification when someone open door, Enable the "Unlock Notification" option in the lock's "Settings" menu. Then the administrator will receive notification when someone open door.

11




All users under the account can view the permissions that are about to expire, modify the validity period in time, and delete the user permissions.

6.5 Authorized Admin

to it.

Find the "Authorized Admin" in the App settings menu You will see current authorized administrators. Click the "+" icon at the top right to create a new admin. In the authorized admin's detail page, you can freeze or de-authorize him, change the validity period, or change locks.







7 Transfer Lock	•••••0中国电性 中	18.59 Select Lock	≁∦ ≡ 0 Cancel	••••••中国电世中	16:59 Recepient	**
to the App "Settings" menu, and find "Transfer k". Select locks and enter the recipient account, the	Q Search	02F_306720		 Personal TTRenting 	I	
ected locks will be transferred to him. bu just want to remove some damaged locks from				Account Caution1 - The Selec	Enter Recipient's Ar ted Lock(s) will be Permanen	-
ount, please click "Move Faulty/Damaged Frash" at the bottom right.					Next	

6.8 Transfer Gateway	****0 0 E E E E E E E E E E E E E E E E	16.59 Choose Gateway	⊀* ⊡ Cancel	••••••	16:59 Recepient	* * 💷
	s 🙆 s	is		Person	al	
Call out the menu interface in the upper left corner				O TTRen	ting	
of the interface, click Settings, select the transfer gateway, select the gateway that needs to be operated, in this interface, you can transfer the gateway to other individual users of TTLock, or transfer to the good house housekeeper user, after the transfer, you will lose the management authority of the gateway.				Account Caution - The S	Enter Racipient's A elected Lock(s) will be Permaner Next	-

12